

Mercedes 2-track 13 cut STOP 4

BLANK \	S34YS-P
WISE \	TIP STOP # 4
CODE JAW \	STOP 3
RIGHT JAW \	3
USE CD300 BLADE\Cutter CW1011	

CUT SHOULD BE IN MANUALLY JUST BEHIND THICK PART OF KEY

STAKE LONG

Copyright 2004, Laser Security Products
*All rights reserved

Mercedes 2-track 13 cut STOP 4

BLANK \	S34YS-P
WISE \	TIP STOP # 4
CODE JAW \	STOP 3
RIGHT JAW \	3
USE CD300 BLADE\Cutter CW1011	

CUT SHOULD BE IN MANUALLY JUST BEHIND THICK PART OF KEY

STAKE LONG

Copyright 2004, Laser Security Products
*All rights reserved